

Model VTW

TIRE AND WHEEL DYNAMIC BALANCE SYSTEM



- **Fast Cycle Time**
- **Best Accuracy and Repeatability**
- **Lowest Total Life-Cycle Cost**
- **Highly Reliable and Maintainable**
- **Fully Automatic**
- **Robust and Dependable**
- **Runs Passenger & Medium/Lt. Truck Tires & Wheels**

Model VTW

TIRE AND WHEEL DYNAMIC BALANCE SYSTEM

Standard Features

- Two-plane Hard Bearing measurement system
 - * Robust, durable suspension and sensors for more accurate “force measurement”
- “Single master” calibration capability
 - * Eliminates multiple masters; Hard bearing not susceptible to part weight
- Integral brushless DC spindle drive servo motor
 - * Superior, maintenance-free drive system without generating forces that distort imbalance data
- Isolated balance station
 - * Separates balance station from outside vibrations that could distort imbalance data
 - * Mid-plane eight correction calculation for adhesive (stick-on) weights
- Fully-automatic single station operation
- PLC Machine Sequence control
- PLC part tracking code information
- Part Identification Input
 - * PC input via N-Command
 - * PLC input via part tracking
 - * Operator code forcing
- Operator interface color touch screen
- Windows®-based Micro-Poise WinMPX computer
- Automatic fixed upper/lower plane contact marking
- Precision balance tooling (collet or multi-jaw style)
- Mini-spare bypass
- Short-reach orient (true and high speed)
- Two-speed elevator with conveyor belt part transfer
- 12 month warranty

Balancer Options

- Upper Marker Configuration Options (standard fixed upper):
 - * Auto 2-position radial upper marker positioner (4 consecutive part sizes)
 - * Auto 3-position radial upper marker positioner (6 consecutive part sizes)
 - * One-axis upper servo marker positioner
 - * High speed option (includes 2-axis upper marker servo positioner)
- Lower Marker Configuration Options (standard fixed lower marker):
 - * Auto 2-position radial lower/mid-plane marker positioner (4 consecutive part sizes)
 - * Auto 3-position radial lower/mid-plane marker positioner (6 consecutive part sizes)
 - * One-axis lower servo marker positioner
- Mid-plane marker configuration option
- Balance/Audit function (software, horn, light)
- In/Out audit feature
- Vision Part Identification System
- Entrance stop pins
- Calibration assembly




Isolated balance station
hard-bearing
measurement system.



TOF-40 weight application station.



Precision multi-jaw tooling.




VTW-235

TOF-40

Typical Balance System Configurations¹


One-man Operation



225-300 Avg. PPH


225-325 Avg. PPH

One-man or Two-man Operation




225-360 Avg. PPH

Two-man Operation



225-360 Avg. PPH

One-man or Two-man Operation



225-360 Avg. PPH

Balancer



Weight Apply / Turnover Fixture



Turnover Fixture with Guard



Weight Apply / Correction Station



Weight Bins & Lights



Buffer Conveyor with Stop Pins



¹ Configurations reflect weight apply layouts and system throughput rates using one-piece pound-on weights. Stick-on or two-piece weight application will reduce system throughput and may require a different system layout (not shown).

Model VTW

TIRE AND WHEEL DYNAMIC BALANCE SYSTEM

Cycle Time: Passenger Tire & Wheel (VTW-229)

Typical Application	Avg. Cycle Time @ 80 psi ¹	Bore Dia. Range (max)	Assy. Weight (max)	Assy O.D. (min/max)	Wheel Bead Dia. (min/max) ²
Standard machine	12 seconds with knock-on weights 12-13.5 seconds with mid plane marking orient ³ for stick-on weights 10 seconds for average audit-only cycle	19 mm	34 kg	500-735 mm	13-20 inch
High Speed Option	10 seconds with knock-on weights 12-13.5 seconds with mid plane marking orient ³ for stick-on weights 10 seconds for average audit-only cycle	¾ inch	75 lbs	19.6-29 inch	

Cycle Time: Light & Medium Truck Tire & Wheel (VTW-235)

Typical Application	Avg. Cycle Time @ 80 psi ¹	Bore Dia. Range (max)	Assy. Weight (max)	Assy O.D. (min/max)	Wheel Bead Dia. (min/max) ²
Standard machine	14 seconds with knock-on weights 14-15.5 seconds with mid plane marking orient ³ for stick-on weights 12 seconds for average audit-only cycle	57 mm	54.5 kg	500-890 mm	14-24 inch
High Speed Option	12 seconds with knock-on weights 14-15.5 seconds with mid plane marking orient ³ for knock-on weights 12 seconds for average audit-only cycle	2 ½ inch	120 lbs	19.6 - 35 inch	

Optional Equipment: Weight Application & Turnover

Model	Typical Application	Average Cycle Time ⁴	Assembly OD (min/max)	Assembly Weight (max)	Modes of Operation
Turnover Fixture (TOF-40)	Passenger car	10 seconds	500-890 mm	34kg / 75 lbs	Operator-initiated, hands-off part turnover & transfer.
	Light & Medium truck	12 seconds	19.6-35 inch	54.5kg / 120 lbs	Automatic part turnover & transfer
Correction Station (CS)	Passenger car	≤10 seconds	500-890 mm	54.5kg / 120 lbs	Single-plane weight apply and powered transfer at weight apply station
	Light & Medium truck		19.6-35 inch		

- System throughput assumes the use of one-piece pound-on weights without short-reach orient. Adhesive stick-on or two-piece clip-on weights will reduce system throughout.
- Multiple part sizes and wheel bead diameters can be processed based on marking options and part identification system. A review of the customer's part drawings is necessary to confirm the actual range of parts that can be run as well as options to be recommended.
- Mid plane mark in front of operator.
- Weight application times are operator dependent and can vary. Two-man weight apply is recommended for 10 second (360 parts per hour) or shorter cycle time.

Micro-Poise Measurement Systems LLC reserves the right to make changes in the specifications shown herein, add improvements, or discontinue manufacture at any time without notice or obligation. Contact your local Micro-Poise representative for the most current information. Windows® is a registered trademark of Microsoft Corporation.



1624 Englewood Avenue,
Akron, OH USA 44305

+1-330-784-1251
www.micropoise.com